



ATLANTIC SUPPLY

QUALITY DRILLING SUPPLIES AND
MATERIALS TESTING EQUIPMENT

www.ScalesForBusiness.com

www.AtlanticSupply.com

BACK-SET

MOLECULAR CEMENT DISSOLVER

Directions for Use:

*Note - Do not wet concrete with water before applying Back-Set.

- Completely saturate area of hardened concrete to be removed with Back-Set via sprayer or soft brush. (Do Not Dilute) Concrete will turn white upon contact, then darken. **IF ALLOWED TO EVAPORATE, WHITE RESIDUE WILL APPEAR. DO NOT RINSE, RE-APPLY BACK-SET TO REACTIVATE AS NEEDED UNTIL CONCRETE IS SOFTENED.**
- Allow Back-Set to penetrate 10-15 minutes. After 10-15 minutes, re-apply Back-Set to same area. Keep surface wet with Back-Set. Concrete will begin to soften and pull away from cleaned surface. (Approximately 20-30 minutes)
- Rinse with water pressure thoroughly. On extra thick buildup repeat cleaning directions until buildup is soft.
- **Surface & Air Temperatures**
Do not clean with any type product when temperatures are below freezing or in extreme heat of direct sun. Best cleaning results are obtained when air and surface temperature are 40° F to 80° F. (Hot surface temperature may cause scorching)
- **Pre-Testing**
Always test prior to beginning full-scale cleaning operation. Testing should confirm cleaning effectiveness on each type surface being cleaned. Test also to determine desired surface contact time and potential for adverse reactions with application. Allow test panels to dry thoroughly before evaluating final appearance and results.

*Note - Always wear eye protection when handling any type of chemical.

*Note - As with any chemical, Back-Set should not be applied to extremely hot surfaces or scorching may occur.

Reminder

**Back-Set does not know good concrete
from bad concrete.**